



# Orion TI-30XS MultiView™ Talking Scientific Calculator QUICK-START GUIDE

©2015, The American Printing House for the Blind, Inc.

This Quick-Start Guide explains how to prepare the Orion TI-30XS MultiView™ to be charged and operational. **It is imperative that this calculator be fully charged prior to first-time use.** Please see the Orion TI-30XS MultiView™ Talking Scientific Calculator Manual and TI-30XS MultiView™ User Guide, found on the accompanying USB flash drive, for more information and details. **Parts List**

Included in the box are the following items:

- Orion TI-30XS MultiView™ Talking Scientific Calculator
- Hard slide cover (PN: 45-004-025)
- Original TI-30XS MultiView™ hard snap cover
- Standard A male to Micro-B male USB cable
- USB wall plug
- Earphones
- USB flash drive with documentation and software
- Quick-Start Guide in braille format □ Quick-Start Guide in print format

## Getting Started

First, unpack all materials and check that everything needed is there. The Orion TI-30XS MultiView™ comes with a built in user-replaceable chargeable battery.

## Procedure for Charging

1. Hold the calculator in its operating position so that the keys are face up and the access keys are toward the top of the device.
2. Plug the Micro-B end of the USB cable into the Micro-B port on the side at the top of the device.
3. Plug the standard A male end of the USB cable into the USB wall adapter.
4. Plug the wall adapter into the wall socket.

**Note:** Fully charge the battery prior to first-time use of the calculator. This should take about 4 hours. The calculator can be used while it is charging.

## Operation Procedure

1. To turn the device on, press the ON key located at the lower left-hand corner of the calculator.

2. To turn the device off, first press the "2nd" key located in the first column on the left, ninth key from the bottom, and then press the ON key.

**Note:** If the calculator is on and not in use for 5 minutes, the Automatic Power Down (APD) feature will automatically power off safely, without loss of data.

## Learn Mode

The Orion TI-30XS MultiView™ is equipped with a Learn mode designed to assist with locating keys and confirming their functionality. Learn mode can be used at any time, even in the middle of a calculation. When the unit is in Learn mode, the calculator retains its previous status.

To enter the Learn mode, press and hold the middle Orion Silence/Learn (S/L) key located at the top of the calculator, above the screen. While in Learn mode, to assist with locating a particular key, each key and its primary function is announced when pressed. When used in combination with the 2nd key, the Orion TI-30XS announces the secondary function for the pressed key.

To exit the Learn mode, press and hold the middle Orion S/L key. The calculator returns to the speech and operational mode used prior to entering Learn mode and restores all the previously set preferences.

## Review and Access Functionality

### Orion Settings

Press and hold the Access key until "Orion settings on" is announced.

Volume Up/Down — Up arrow/Down arrow

Rate Up/Down — Right arrow/Left arrow

### Review Mode Keys

Tap the Access key first, then press the relevant arrow key.

Line review — Up arrow/Down arrow

Character review — Right arrow/Left arrow

For more information about review and access functionality, please see the Orion TI30XS MultiView™ User Guide, found on the accompanying USB flash drive.

